Memory Stick® Media Compatibility Information for Sony® Digital Cameras

Important Information:

- This "Compatibility Chart" only provides compatibility testing results for the Memory Stick media applications listed in each product's instruction manual with Memory Stick media types listed below.
- This chart does not guarantee support for all Memory Stick media types' performance nor compatibility among Memory Stick media compliant products.
- Memory Stick media transmission speed varies by, and depends on, host hardware devices' features and circumstances of use.
- The recording time and the number of still images that can be recorded will vary by device. Refer to the instruction manual supplied with your camera for more information.
- Attach a dedicated adapter to use Memory Stick Duo™ media in a slot for standard size media.
- The Memory Stick media capacity indicated on the packaging will differ from actual usable capacity. A portion of the memory is used for data management file functions. Refer to the back of the packaging for the minimum guaranteed capacity. Click here to view the Memory Stick media user capacity chart.
- This compatibility chart and specifications are subject to change without notice.

Notes:

2	The Transmission speed may not be faster when using Memory Stick PRO™ (High Speed/Mark2) and Memory Stick PRO-HG™.
4	A dedicated adapter must be attached to use the Memory Stick Micro™ media .
7	This Memory Stick™ may not be able to record or play video.
9	Use a Memory Stick™ 1GB or over when shooting video.
13	Use the AD-MSCF1 Memory Stick™ adaptor for Memory Stick Duo™ media.
18	The recording failure of sound may occur by pushing the DIVIDE button during recording.
20	The recording failure of sound may briefly occur while pre-recording buffer is activated.
37	This media is not compatible with HD movie mode.
39	TransferJet function is not available for use with this product.
41	This media cannot be used in "Standard mode" as file system is different.
42	This media cannot be used when Secure Access is set to ON. Please switch off Secure Access function, using the software Memory Media Utility.
43	Mirroring function is not available for use with this product.
44	This media is not compatible with simultaneous movie recording in Standard mode.
45	This media is not compatible with simultaneous movie recording.
53	This media is not compatible with XAVC S movie mode.

Camera	Memory Stick										
	MS-A16G	MS-A16GU2	MS-A1G	MS-A1GN	MS-A1GU2	MS-A256	MS-A2G	MS-A2GN	MS-A2GU2	MS-A4G	MS-A4GN
DSC-G3	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-H20	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-H200	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-H300	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-H400	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-H55	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-H70	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-H90	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX100V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX10V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX200V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX20V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX300	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX30V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX400V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX50V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX5V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX60V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX7V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-HX9V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-J10	-	-	-	-	-	-	-	-	-	-	-
DSC-RX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-RX10	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-RX100	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-RX100M2	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-RX100M3	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-RX1R	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-S2000	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37

Camera	Memory Stick										
	MS-A16G	MS-A16GU2	MS-A1G	MS-A1GN	MS-A1GU2	MS-A256	MS-A2G	MS-A2GN	MS-A2GU2	MS-A4G	MS-A4GN
DSC-S2100	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-S930	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-S950	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-S980	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-T110	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-T110D	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-T90	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-T900	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-T99	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-T99D	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-TF1	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-TX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-TX10	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-TX100V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-TX20	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-TX200V	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-TX30	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-TX5	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-TX55	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-TX66	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-TX7	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-TX9	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W180	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W190	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W210	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W215	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W220	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W230	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W270	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W275	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37

Camera	Memory Stick										
	MS-A16G	MS-A16GU2	MS-A1G	MS-A1GN	MS-A1GU2	MS-A256	MS-A2G	MS-A2GN	MS-A2GU2	MS-A4G	MS-A4GN
DSC-W290	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W310	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W320	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W330	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W350	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W370	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W390	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W510	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W530	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W550	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W560	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W570	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W570D	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W610	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W620	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W630	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W650	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W670	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W690	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W710	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W730	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W800	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-W830	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX10	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX100	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX150	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX200	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX220	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX300	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37

Camera	Memory Stick										
	MS-A16G	MS-A16GU2	MS-A1G	MS-A1GN	MS-A1GU2	MS-A256	MS-A2G	MS-A2GN	MS-A2GU2	MS-A4G	MS-A4GN
DSC-WX350	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX5	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX50	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX60	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX7	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX70	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX80	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37
DSC-WX9	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37

Camera	Memory Stick										
	MS-A4GU2	MS-A512	MS-A8G	MS-A8GN	MS-A8GU2	MS-EX1G	MS-EX2G	MS-EX4G	MS-HX16A	MS-HX16AG	MS-HX16B
DSC-G3	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-H20	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-H200	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-H300	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-H400	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-H55	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-H70	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-H90	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX100V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX10V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX200V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX20V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX300	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX30V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX400V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX50V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX5V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX60V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX7V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-HX9V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-J10	-	-	-	-	-	-	-	-	-	-	-
DSC-RX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-RX10	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-RX100	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-RX100M2	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-RX100M3	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53
DSC-RX1R	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-S2000	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK

Camera	Memory Stick										
	MS-A4GU2	MS-A512	MS-A8G	MS-A8GN	MS-A8GU2	MS-EX1G	MS-EX2G	MS-EX4G	MS-HX16A	MS-HX16AG	MS-HX16B
DSC-S2100	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-S930	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-S950	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-S980	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-T110	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-T110D	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-T90	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-T900	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-T99	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-T99D	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-TF1	OK *37	OK *37	OK *37	OK *37	OK *37	-	-	-	-	-	-
DSC-TX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-TX10	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-TX100V	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-TX20	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-TX200V	OK *37	OK *37	OK *37	OK *37	OK *37	-	-	-	-	-	-
DSC-TX30	OK *37	OK *37	OK *37	OK *37	OK *37	-	-	-	-	-	-
DSC-TX5	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-TX55	OK *37	OK *37	OK *37	OK *37	OK *37	-	-	-	-	-	-
DSC-TX66	OK *37	OK *37	OK *37	OK *37	OK *37	-	-	-	-	-	-
DSC-TX7	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-TX9	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W180	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W190	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W210	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W215	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W220	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W230	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W270	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W275	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK

Camera	Memory Stick										
	MS-A4GU2	MS-A512	MS-A8G	MS-A8GN	MS-A8GU2	MS-EX1G	MS-EX2G	MS-EX4G	MS-HX16A	MS-HX16AG	MS-HX16B
DSC-W290	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W310	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W320	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W330	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W350	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W370	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W390	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W510	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W530	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W550	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W560	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W570	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W570D	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W610	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W620	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W630	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W650	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W670	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W690	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W710	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W730	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W800	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-W830	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX1	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX10	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX100	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX150	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX200	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX220	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX300	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK

Camera	Memory Stick										
	MS-A4GU2	MS-A512	MS-A8G	MS-A8GN	MS-A8GU2	MS-EX1G	MS-EX2G	MS-EX4G	MS-HX16A	MS-HX16AG	MS-HX16B
DSC-WX350	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX5	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX50	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX60	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX7	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX70	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX80	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK
DSC-WX9	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK *4*37	OK	OK	OK	OK	OK	OK

Camera	Memory Stick										
	MS-HX16G	MS-HX32A	MS-HX32AG	MS-HX32B	MS-HX32G	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G
DSC-G3	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-H20	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-H200	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-H300	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-H400	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-H55	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-H70	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-H90	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-HX1	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-HX100V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX10V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX200V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX20V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX300	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-HX30V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX400V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-HX50V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-HX5V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX60V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-HX7V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX9V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-J10	-	-	-	-	-	-	-	-	-	-	-
DSC-RX1	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-RX10	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-RX100	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-RX100M2	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-RX100M3	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *39 *53
DSC-RX1R	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-S2000	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39

Camera	Memory Stick										
	MS-HX16G	MS-HX32A	MS-HX32AG	MS-HX32B	MS-HX32G	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G
DSC-S2100	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-S930	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-S950	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-S980	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-T110	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-T110D	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-T90	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-T900	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-T99	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-T99D	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-TF1	-	-	-	-	-	-	-	-	-	-	-
DSC-TX1	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-TX10	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-TX100V	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-TX20	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	-
DSC-TX200V	-	-	-	-	-	-	-	-	-	-	-
DSC-TX30	-	-	-	-	-	-	-	-	-	-	-
DSC-TX5	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-TX55	-	-	-	-	-	-	-	-	-	-	-
DSC-TX66	-	-	-	-	-	-	-	-	-	-	-
DSC-TX7	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-TX9	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W180	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W190	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W210	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W215	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W220	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W230	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W270	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W275	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39

Camera	Memory Stick										
	MS-HX16G	MS-HX32A	MS-HX32AG	MS-HX32B	MS-HX32G	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G
DSC-W290	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W310	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W320	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W330	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W350	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W370	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W390	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W510	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W530	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W550	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W560	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W570	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W570D	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W610	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W620	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W630	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W650	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W670	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W690	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W710	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W730	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W800	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-W830	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-WX1	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-WX10	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX100	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX150	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX200	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-WX220	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-WX300	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39

Camera	Memory Stick										
	MS-HX16G	MS-HX32A	MS-HX32AG	MS-HX32B	MS-HX32G	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G
DSC-WX350	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-WX5	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX50	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX60	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-WX7	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX70	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX80	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK *39
DSC-WX9	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK

Camera	Memory Stick										
	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G	MS-MT8G	MS-PX16	MS-PX32
DSC-G3	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-H20	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-H200	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-H300	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-H400	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-H55	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-H70	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-H90	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX1	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-HX100V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-HX10V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX200V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX20V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX300	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX30V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX400V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX50V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX5V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-HX60V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-HX7V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-HX9V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-J10	-	-	-	-	-	-	-	-	-	-	-
DSC-RX1	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-RX10	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-RX100	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-RX100M2	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-RX100M3	OK *4 *53	OK *4 *53	OK *4 *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53	OK *53
DSC-RX1R	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-S2000	-	-	-	OK	OK	OK	OK	OK	OK	-	-

Camera	Memory Stick										
	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G	MS-MT8G	MS-PX16	MS-PX32
DSC-S2100	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-S930	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-S950	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-S980	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-T110	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-T110D	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-T90	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-T900	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-T99	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-T99D	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-TF1	OK	OK	OK	-	-	-	-	-	-	-	-
DSC-TX1	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-TX10	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-TX100V	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-TX20	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-TX200V	OK	OK	OK	-	-	-	-	-	-	-	-
DSC-TX30	OK	OK	OK	-	-	-	-	-	-	-	-
DSC-TX5	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-TX55	OK	OK	OK	-	-	-	-	-	-	-	-
DSC-TX66	OK	OK	OK	-	-	-	-	-	-	-	-
DSC-TX7	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-TX9	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W180	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W190	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W210	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W215	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W220	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W230	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W270	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W275	-	-	-	OK	OK	OK	OK	OK	OK	-	-

Camera	Memory Stick										
	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G	MS-MT8G	MS-PX16	MS-PX32
DSC-W290	-	-	-	OK	OK	OK	OK	OK	OK	-	-
DSC-W310	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W320	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W330	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W350	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W370	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W390	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W510	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W530	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W550	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W560	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W570	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W570D	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W610	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W620	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W630	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W650	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W670	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W690	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W710	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-W730	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W800	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-W830	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX1	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-WX10	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-WX100	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX150	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX200	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX220	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX300	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK

Camera	Memory Stick										
	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G	MS-MT8G	MS-PX16	MS-PX32
DSC-WX350	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX5	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-WX50	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX60	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX7	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-
DSC-WX70	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX80	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	OK	OK
DSC-WX9	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK	OK	-	-

Camera	Memory Stick								
	MS-PX64	MSX-M1GS	MSX-M1GST	MSX-M256	MSX-M256S	MSX-M2GS	MSX-M4GS	MSX-M512S	MSX-M8GS
DSC-G3	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-H20	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-H200	-	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-H300	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-H400	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-H55	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-H70	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-H90	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX1	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-HX100V	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-HX10V	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX200V	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX20V	OK	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-HX300	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX30V	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX400V	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX50V	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX5V	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-HX60V	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-HX7V	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-HX9V	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-J10	-	-	-	-	-	-	-	-	-
DSC-RX1	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-RX10	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-RX100	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-RX100M2	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-RX100M3	OK *53	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-RX1R	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-S2000	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK

Camera	Memory Stick								
	MS-PX64	MSX-M1GS	MSX-M1GST	MSX-M256	MSX-M256S	MSX-M2GS	MSX-M4GS	MSX-M512S	MSX-M8GS
DSC-S2100	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-S930	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-S950	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-S980	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-T110	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-T110D	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-T90	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-T900	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-T99	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-T99D	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-TF1	-	-	-	-	-	-	-	-	-
DSC-TX1	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-TX10	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-TX100V	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-TX20	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-TX200V	-	-	-	-	-	-	-	-	-
DSC-TX30	-	-	-	-	-	-	-	-	-
DSC-TX5	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-TX55	-	-	-	-	-	-	-	-	-
DSC-TX66	-	-	-	-	-	-	-	-	-
DSC-TX7	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-TX9	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W180	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W190	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W210	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W215	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W220	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W230	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W270	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W275	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK

Camera	Memory Stick								
	MS-PX64	MSX-M1GS	MSX-M1GST	MSX-M256	MSX-M256S	MSX-M2GS	MSX-M4GS	MSX-M512S	MSX-M8GS
DSC-W290	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W310	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W320	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W330	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W350	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W370	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W390	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W510	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W530	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W550	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W560	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W570	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W570D	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-W610	-	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W620	-	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W630	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W650	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W670	-	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W690	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W710	-	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W730	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W800	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-W830	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX1	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-WX10	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-WX100	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX150	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX200	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX220	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX300	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37

Camera	Memory Stick								
	MS-PX64	MSX-M1GS	MSX-M1GST	MSX-M256	MSX-M256S	MSX-M2GS	MSX-M4GS	MSX-M512S	MSX-M8GS
DSC-WX350	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX5	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-WX50	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX60	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX7	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK
DSC-WX70	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX80	OK	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37	OK *37
DSC-WX9	-	OK	OK	OK *37	OK *37	OK	OK	OK *37	OK